


SEAT OCCUPANT SENSOR EMULATOR



Possible modes:

1. Older **BMW** E38 E39 E46 E53 E83 and similar where direct connection to AIRBAG ECU takes place. NOT working where seat modules are connected directly to K-BUS.

OCCUPIED:

Jumper 2 – SHORTED

Jumper 1 – SHORTED

NOT OCCUPIED:

Jumper 2 – SHORTED

2. **Mercedes Benz** (1997...2001) TRW Airbag unit – A-class W168, C-class W202, Vito W638, ML etc.

OCCUPIED:

Jumper 3 – SHORTED

Jumper 1 – SHORTED

NOT OCCUPIED:

Jumper 3 – SHORTED

3. **Mercedes Benz** (2000...2002) A-class W168, C-class W203, CLK W209, Vaneo, E-class W210, S-class W220, Vito W639, ML W163 etc.

OCCUPIED:

Jumper 4 – SHORTED

Jumper 1 – SHORTED

NOT OCCUPIED:

Jumper 4 – SHORTED

By default device is shipped in mode **BMW, OCCUPIED** as pictured:

